


Condensed Instructions

IFC 210 E IFC 210 E-EEEx

Signal converters for electromagnetic flowmeters



Applicable to Software Versions

- Operating and check elements
No. **3.18393.01**
- Amplifier (ADC)
No. **3.17116.01**
- Outputs/inputs (I/O)
No. **3.19005.01**

Contents

1	Electrical connection: Power	Pages	2-11
2	Electrical connection: Outputs	Pages	12-18
3	Start-up	Pages	19
4	Operator control of signal converter	Pages	20-27

PLEASE NOTE

These concise instructions do not include the following:
device description, technical data, standards, approvals, etc.,
nor conditions pertaining to product liability and warranty.

The operator is, however, obligated to take note of these sections in the detailed Installation and Operating Instructions.

References to chapters

All references to chapters in these Condensed Instructions refer to those of the detailed "Installation and Operating Instructions". It is important that the detailed Instructions be referred to for all chapters omitted from these Condensed Instructions. This particularly concerns installation and operation in hazardous areas!

1 Electrical connection: power supply

1.1 Location and important installation notes

- **Electrical connection in accordance with VDE 0100** "Regulations governing heavy-current installations with line voltages up to 1000 V" or **equivalent others national regulations**.
- Do not cross or loop **cables**.
- Use **separate cable** entries (see below) for power supply, field current cables, signal lines, outputs and inputs.
- Protect flowmeters or switchgear cabinets with built-in devices from direct **sunlight**. Fit a sunshade if necessary.
- When **installed in switchgear cabinets**, signal converters must be adequately cooled, e.g. use fans or heat exchangers. (dust-free air and no aggressive gases)
- Do not expose signal converters to intense **vibration**.
- Keep **distance between primary head and signal converter** as short as possible. Refer to Sect. 1.3.4 for maximum permissible length of signal and field current cables.
- Use the supplied KROHNE **signal cable A** (Type DS), standard length 10 m (33 ft), or optional **signal cable B** (Type BTS).
- Always **calibrate** primary head and signal converter **together**. Therefore, when installing, ensure **primary constant GK is identical**; refer to instrument nameplate for the primary head.
If the GK is not identical, set the signal converter to the GK of the primary head.
Refer also to Section 4.
- **Dimensions of signal converter**, refer to Section 10.4.



IMPORTANT!

For EEx versions, also pay regard to all special directions included in Sect. 6.1 and 13.

**Only the EEx primary head may be installed in the hazardous area.
The signal converter must be installed outside the hazardous area!**

1.2 Power supply - Electrical connection

PLEASE NOTE !

- **Rated values:** The flowmeter housings meets the requirements of IP 20 in conformity with EN 60529.
No protection against water and moisture. If necessary, take appropriate protective measures.
The selected creepage distances and clearances have been dimensioned in conformity with VDE 0110 and IEC 664 for contamination category 2. Supply circuits and output circuits are designed to meet the standards of overvoltage class II.
- **Fuse protection, disconnecting device:** fuse protection for the feeding power circuit, and also a disconnecting device (switch, circuit breaker) for isolating the signal converters must be provided (see also Sect. 1.3.5).

Power supply 100-230 V AC (Tolerance zone: 85-255 V AC)

- **Note information on instrument nameplate:** supply voltage and frequency
- **Connection diagrams** for electrical connection between primary head and signal converter: refer to Section 1.3.5.

Power supply 24 Volt AC / DC (Tolerance zone: AC 20.4 - 26.4 V / DC 18 - 31.2 V)

- **Note information on instrument nameplate:** supply voltage and frequency
- For measurement reasons, connect an **FE functional ground conductor**.
- If connected to a functional extra-low voltage source (24 V AC / DC, 48 V AC), provide for **protective separation (PELV)** in conformity with e.g. VDE 0100 / VDE 0106 or IEC 364 / IEC 536, or equivalent national regulations.
- **Connection diagrams** for power supply and electrical connection between primary head and signal converter: refer to Section 1.3.5.



IMPORTANT!

For EEx versions, also pay regard to all special directions included in Sect. 6.1 and 13.

**Only the EEx primary head may be installed in the hazardous area.
The signal converter must be installed outside the hazardous area!**


1.3 Electrical connection of separate primary heads

1.3.1 General remarks on signal lines A and B and field current line C


Proper operation of the equipment is ensured when KROHNE signal lines A and B are used with foil screen and magnetic shield.

- Signal lines must be firmly installed.
- Shields are connected via stranded drain wires.
- Underwater or underground routing is possible.
- Insulating material flame-retardant to IEC 332.1 / VDE 0742.
- Low-halogen, unplasticized signal lines which remain flexible at low temperatures.

Signal line A (type DS) with double shielding



Signal line B (type BTS) with triple shielding (bootstrap line)



Field current line C

Line 2 × 0,75 mm², 2 × 1,5 mm² or 4 × 1,5 mm²Cu, single shielding
 (Cu = copper cross section)

The cross section depends on the required cable length, see table in Section 1.3.4.



IMPORTANT!

For EEx versions, also pay regard to all special directions included in Sect. 6.1 and 13.

**Only the EEx primary head may be installed in the hazardous area.
 The signal converter must be installed outside the hazardous area!**

1.3.2 Stripping (preparation) of signal cables

Please note: The numbers in the drawings designate the stranded drain wires of signalling cables A and B, see sectional drawings in Sect. 1.3.1.

primary head



Converter

Length	primary head	
	mm	inch
a	90	3.60
b	8	0.30
c	25	1.00
d	8	0.30
e	70	2.80

Length	Converter	
	mm	inch
a	40	2.80
b	10	0.30
d	5	0.30
e	20	2.00



**Signal cable A (type DS),
double shielding
for primary head**

**Signal cable A (type DS),
double shielding
for IFC 210 E Converter**



**Signal line B (type BTS),
with triple shielding (bootstrap)
for primary head**

**Signal line B (type BTS),
with triple shielding (bootstrap)
for IFC 210 E Converter**



Customer-supplied materials

V	Tin-coat all stranded drain wire ends!
W	Insulation tubing (PVC), Ø 2.0-2.5 mm (Ø 1")
X	Heat-shrinkable tubing or cable sleeve
Y	Wire end sleeve to DIN 41 228: E 1.5-8
Z	Wire end sleeve to DIN 41 228: E 0.5-8

1.3.3 Grounding of primary head

- All flowmeters must be grounded.
- The grounding conductor should not transmit any interference voltages.
- Do not ground any other electrical device together with this conductor.
- The primary head is connected to ground by means of an **FE functional ground conductor**.
- Special information on grounding various primary heads is contained in the separate **installation instructions for primary heads**.
- These instructions also contain detailed descriptions on how to use grounding rings and how to install primary heads in metal or plastic pipes or internally coated pipelines.



IMPORTANT!

For EEx versions, also pay regard to all special directions included in Sect. 6.1 and 13.

**Only the EEx primary head may be installed in the hazardous area.
The signal converter must be installed outside the hazardous area!**

1.3.4 Cable lengths (max. distance between signal converter and primary head)

Abbreviations and explanatory notes

used in the following tables, diagrams and connection diagrams

- A** Signal cable A (type DS), with double shielding, see diagram A for max. length
- B** Signal line B (type BTS) with triple shielding, max. length see diagram B
- C** Field current cable min. cross-section (A_F) and max. length, see Table
- D** High-temperature silicone cable, $3 \times 1.5 \text{ mm}^2$ (14 AWG) Cu, (with single shielding, max. length 5 m (16 ft))
- E** High-temperature silicone cable, $2 \times 1.5 \text{ mm}^2$ (14 AWG) Cu, max. length 5 m (16 ft)
- A_F** Cross section of field current line C in Cu, see table
- L** Cable length
- κ** Electrical conductivity of the process liquid
- ZD** Intermediate connection box required in connection with cables D and E for primary heads ALTOFLUX IFS 4000 F, PROFIFLUX IFS 5000 F and VARIFLUX IFS 6000 F in cases where process temperatures exceed $150 \text{ }^\circ\text{C}$ ($302 \text{ }^\circ\text{F}$)

Recommended length of signal cable A (Type DS) and B (Type BTS)

Primary head	Meter size		Signal cable	
	DN mm	inch	A	B
AQUAFLUX F	10 - 1600	³ / ₈ - 64	A1	B1
ECOFLUX IFS 1000 F	10 - 15	³ / ₈ - ½	A4	B3
	25 - 150	1 - 6	A3	B2
ALTOFLUX IFS 2000 F	150 - 250	6 - 10	A1	B1
ALTOFLUX IFS 4000 F	10 - 150	³ / ₈ - 6	A2	B2
	200 - 1600	8 - 64	A1	B1
PROFILUX IFS 5000 F	2.5 - 15	¹ / ₁₀ - ½	A4	B3
	25 - 100	1 - 4	A2	B2
VARIFLUX IFS 6000 F	2.5 - 15	¹ / ₁₀ - ½	A4	B3
	25 - 80	1 - 3	A2	B2
ALTOFLUX M 900	10 - 300	³ / ₈ - 12	A1	B1

Diagram A





Diagram B



Field current cable C

Length L	Cross section A _F (Cu), minimum
0 – 150 m 5 – 500 ft	2 x 0.75 mm ² / 2 x 18 AWG
150 – 300 m 500 – 1000 ft	2 x 1.50 mm ² / 2 x 14 AWG
300 – 600 m 1000 – 1900 ft	4 x 1.50 mm ² / 2 x 12 AWG

1.3.5 Connection diagrams for power supply and primary head

PLEASE NOTE: Undocumented contacts/terminals to remain unwired.

The figures in brackets indicate the stranded drain wires for the shields (see cross-sectional drawing of signal cable in Section 1.3.1).

- Electrical connection to VDE 0100 "Regulations governing heavy-current installations with line voltages up to 1000 V" or equivalent national regulations.
- 24 V AC / DC power supply: Functional extra-low voltage with protective separation in conformity with VDE 0100, Part 410 or equivalent national regulations (IFC 020 E: 24 V DC in preparation).
- Fuse protection of the feed line circuit with $I_{RAT} \leq 16$ A is required. Also, a disconnecting device (switch/circuit breaker) must be provided in the vicinity of the solidly connected signal converters or device groups, refer to EN 61 010. This disconnecting device must be easy to reach and also identifiable as such.

* Contacts **2d, 2z, 4d, 4z** of **XA** must be electrically connected.

** Connection to **8d** and/or **8z** of **XA**.

*** Contacts **d2 to d32** of **XB** are of leading type, for connection of **PE** (safety conductor) or **FE** (functional ground). **At least 4 contacts** with adequate cross-section to be electrically connected.



Important:


Electrical connection of EEx primary heads and EEx signal converters
To be carried out as described in Sect. 1.3.6.

Process temperature < 150°C (302°F)

I Signal cable A (type DS)


II Signal cable B (type BTS)

IFC 210 E



Primary head

IFC 210 E




Primary head

Process temperature > 150°C (302°F)

III Signal cable A (type DS)


IV Signal cable B (type BTS)

IFC 210 E



Primary head

IFC 210 E



Primary head

1.3.6 EEx-Connection diagrams for power supply and primary head

Connection diagrams

PLEASE NOTE: Undocumented contacts/terminals to remain unwired.

The figures in brackets indicate the stranded drain wires for the shields (see cross-sectional drawing of signal cable in Section 1.3.1).

- Electrical connection to VDE 0100 "Regulations governing heavy-current installations with line voltages up to 1000 V" or equivalent national regulations.
- 24 V AC / DC power supply: Functional extra-low voltage with protective separation in conformity with VDE 0100, Part 410 or equivalent national regulations (IFC 020 E: 24 V DC in preparation).
- Fuse protection of the feed line circuit with $I_{RAT} \leq 16$ A is required. Also, a disconnecting device (switch/circuit breaker) must be provided in the vicinity of the solidly connected signal converters or device groups, refer to EN 61 010. This disconnecting device must be easy to reach and also identifiable as such.


* Contacts **2d, 2z, 4d, 4z** of **XA** must be electrically connected.

** Connection to **8d** and/or **8z** of **XA**.

*** Contacts **d2 to d32** of **XB** are of leading type, for connection of **PE** (safety conductor) or **FE** (functional ground).
At least 4 contacts with adequate cross-section to be electrically connected.



Important:


In respect of EEx versions, pay regard to all directions marked with the  symbol, and also the information given in Sect. 6.1 and 13.

**Only the EEx primary head may be installed in the hazardous area.
The signal converter must be installed outside the hazardous area!**

Process temperature < 150°C (302°F)


I Signal cable A (type DS)

IFC 210 E-EEEx



II Signal cable B (type BTS)


IFC 210 E-EEEx



Process temperature > 150°C (302°F)


III Signal cable A (type DS)

IFC 210 E-EEEx



IV Signal cable B (type BTS)

IFC 210 E-EEEx



2 Electrical connection of outputs and inputs



Important:


In respect of EEx versions, pay regard to all directions marked with the symbol, and also the information given in Sect. 6.1 and 13.

**Only the EEx primary head may be installed in the hazardous area.
The signal converter must be installed outside the hazardous area!**

2.1 Current output I

- The current output is galvanically isolated from all input and output circuits.
- Setting data and functions can note down in Section 3.3.
Please also refer to Sect. 3.2 Factory settings.

- Typical current output



- All operating data and functions can be set, see Sect. 4 and 5.6, Fct. 1.05 for operator control
- The current output can also be used as an internal voltage source for the binary outputs and inputs.
- $U_{\text{int}} = 22-25 \text{ V DC}$ $I = 23 \text{ mA}$ when operated **without** receiver instruments at the current output
 $I = 3 \text{ mA}$ when operated **with** receiver instruments at the current output
- **Connection diagrams**, see Sect. 2.5: diagrams ① ② ③ ⑤ ⑦ ⑨ ⑩

2.2 Pulse output P

- The pulse output is galvanically isolated from the current output and all input circuits.
- Setting data and functions can be noted down in Section 3.3.
Please also refer to Sect. 3.2 Factory settings.
- Typical pulse output P




- All operating data and functions can be set, see Sect. 4 and 5.7, Fct. 1.06 for operator control
- The pulse output can be operated in the active or passive mode.
- Active mode: The current output is the internal voltage source, connection of electronic totalizers (EC)
- Passive mode: External DC or AC voltage source required, connection of electronic (EC) or electromechanical (EMC) totalizers

Please note:
A fixed pulse width (0.01 – 1s) must be set for operation with EMC totalizer . Only then is an optocoupler active for higher output currents.

- Digital pulse division, interpulse period is non-uniform. Therefore, if frequency meters or cycle counters are connected, allow for minimum counting interval:
- gate time, counter $\leq \frac{1000}{P_{100\%} [\text{Hz}]}$
- **Connection diagrams**, see Sect. 2.5: diagrams ③ ④ ⑨ ⑩

2.3 Status outputs B1 and B2

- The status outputs are galvanically isolated from the current output and all input circuits.
- Setting data and functions can be noted down in Section 3.3.
Please also refer to Sect. 3.2 Factory settings.
- Typical status outputs B1 and/or B2



- All operating data and functions can be set, see Sect. 4 and 5.9, Fct 1.07 and/or 1.08 for operator control

The status outputs can be operated in the active or passive mode.

Active mode: The current output is the internal voltage source.


Passive mode: External DC or AC voltage source required.

Characteristics of the status outputs	Switch open	Switch closed
OFF (switched off)	no function	
ON (e.g. operation indicator)	power OFF	Hilfsenergie EIN
SIGN I (F/R mode)	Forward flow	Reverse flow
SIGN P (F/R mode)	Forward flow	Reverse flow
TRIP POINT (limit switch)	inactive	active
AUTO RANGE (automatic range change)	high range	low range
OVERFLOW I (I overranged)	current output OK	current output overranged
OVERFLOW. P (P overranged)	pulse output OK	pulse output overranged
SMU I (low-flow cutoff active)	Inactive	active
SMU P (low-flow cutoff active)	Inactive	active
Inverse B1 (switches B2 inversely to B1)	B2 open, B1 closed	B2 closed, B1 open
ALL. ERROR (all errors)	errors	no error
FATAL.ERROR (fatal errors only)	errors	no error
EMPTY PIPE (option)	when measuring tube is empty	when measuring tube is full

- **Connection diagrams**, see Sect. 2.5: diagrams ⑤ ⑥ ⑨ ⑩

2.4 Control inputs B1 and B2

- The control inputs are galvanically isolated from the current output and all input circuits.
- Setting data and functions can note down in Section 3.3.
Please also refer to Sect. 3.2 Factory settings.
- Typical current inputs B1 and B2





- All operating data and functions can be set, see Sect. 4 and 5.10, Fct 1.07 and/or 1.08 for operator control
- The control inputs must be operated in the passive mode.

Function of the control inputs	inactive no voltage	active voltage present
Off	No functions	
External range	High range	Low range
Hold measured values	Measured values follow the measurement	Hold measured values
Measured values at zero	Measured values follow the measurement	Measured values set to "zero"
Reset totalizer	inactive	Reset totalizer
Delete errors	inactive	Delete error messages

Connection diagram, see Sect. 2.5: diagram ⑦ ⑧

2.5 Connection diagrams for outputs and inputs



Important:
 In respect of EEx versions, pay regard to all directions marked with the  symbol, and also the information given in Sect. 6.1 and 13.
Only the EEx primary head may be installed in the hazardous area.
The signal converter must be installed outside the hazardous area!

I Current output (included HART®)

Please note ! Unwired contacts may not have any conductive connection with other electrically conducting parts.

P Pulse output

B1, B2 Status output (**S**) and / or Control input (**C**)

Electrical connection to socket connector XC
 Wiring diagrams ① to ⑩ of outputs and inputs.



Totalizer
 - electromechanical (EMC)
 - electronic (EC)

Interface operation with HART® or RS 485 (Option) see Sect. 6.2.1 and 6.2.2.



milliammeter
 0-20 mA or 4-20 mA and other

Active mode

Power for operation (activation) of outputs and inputs supplied by the current output.



Key, N/O contact



External voltage source (U_{ext}),
 DC or AC voltage,
 connection polarity arbitrary

Passive mode


External power source required for operation (activation) of outputs and inputs.



DC voltage,
 external power source (U_{ext}),
 note connection polarity


① Current output I_{aktiv}

$U = 0/4-20$ mA
 $R_L < 800 \Omega$




② Current output I_{passiv}

$U_{ext} \quad 15-22$ V DC $22-32$ V DC
 $R_L \quad 0-500 \Omega$ $0-800 \Omega$
 $I = 0/4-20$ mA



③ **Pulsoutput P_{activ}**
for electronic totalizer (EC)

$U_{int} = 22-25$ V DC from current output
 $I_{max} \leq 3$ mA operation **with** current output I
 $I_{max} \leq 23$ mA operation **without** current output I




$R = 10$ k Ω , prevents incorrect counts when pulse output in open circuit

Where frequencies are > 100 Hz, use shielded cables (RFD)

④ **Pulsoutput P_{passiv}**
for electronic totalizer (EC) or electromechanical totalizer (EMC)

EMC: $U_{ext} \leq 32$ V DC / ≤ 24 V AC
 $I_{max} \leq 150$ mA $f \leq 50$ Hz
EC: $U_{ext} \leq 32$ V DC $I_{max} \leq 20$ mA

Pulses	≤ 1 kHz	< 10 kHz
R (load)	1-10 k Ω	1-3 k Ω




$R =$ load impedance with EC totalizer operation; for value refer to table above

Where frequencies are > 100 Hz, use shielded cables (RFD)


⑤ **Statusoutput S_{activ}**
(connection to B2 and/or B1)

$U_{int} = 22-25$ V DC from current output
 $I_{max} \leq 3$ mA operation **with** current output I
 $I_{max} \leq 23$ mA operation **without** current output I




⑥ **Statusoutput S_{passiv}**
(connection to B2 and/or B1)

$U_{ext} \leq 32$ V DC / ≤ 24 V DC
 $I_{max} \leq 150$ mA




⑦ **Control input C_{active}**
(connection to B2 and/or B1)

$U_{int} = 22-25 \text{ V DC}$ from current output
 $I_{con} \leq 4 \text{ mA}$ (max. contact rating)




⑧ **Control input C_{passive}**
(connection to B2 and/or B1)

$U_{ext} \leq 32 \text{ V DC} / \leq 24 \text{ V AC}$
 $I_{con} \leq 6 \text{ mA}$ (max. contact rating)



⑨ **F/R measurement (F=forward) (R=reverse)**
Current output I_{active} and/or
pulse output P_{active} (for EC)
without external changeover relay

$U_{int} = 22-25 \text{ V DC}$ from current output
 $I_{max} \leq 3 \text{ mA}$ operation **with** current output I
 $I_{max} \leq 23 \text{ mA}$ operation **without** current output I




$R = 10 \text{ k}\Omega$, prevents incorrect counts
when pulse output in open circuit

* Where frequencies are $> 100 \text{ Hz}$, use shielded
cables (RFD)

⑩ **F/R measurement (F=forward) (R=reverse)**
Current output $I_{passive}$ and/or
pulse output $P_{passive}$ (for EC or EMC)
without external changeover relay

EMC: $U_{ext} \leq 32 \text{ V DC} / \leq 24 \text{ V AC}$
 $I_{max} \leq 150 \text{ mA}$ $f \leq 50 \text{ Hz}$
EC: $U_{ext} \leq 32 \text{ V DC}$ $I_{max} \leq 20 \text{ mA}$

Pulses	$\leq 1 \text{ kHz}$	$< 10 \text{ kHz}$
R (load)	1-10 $\text{k}\Omega$	1-3 $\text{k}\Omega$



$R =$ load impedance with EC totalizer operation; for
value refer to table above

* Where frequencies are $> 100 \text{ Hz}$, use shielded
cables (RFD)

3 Start-up

3.1 Power-on and measurement

- Before powering the system, please check that it has been correctly installed according to Sect. 1 and 2.
- The flowmeter is delivered ready for operational use. All operating data have been factory set in accordance with your specifications.
Please refer to Sect. 3.2 “factory settings”.
- Power the unit, and the flowmeter will immediately start process flow measurement.
- Refer to Sect. 4 and 5 for operator control.

3.2 Factory setting

All operating data are factory set according to your order specifications.

If you have not made any particular specifications at the time of ordering, the instruments will be delivered with the standard parameters and functions listed in the Table below.

To facilitate easy and rapid initial start-up, current output and pulse output are set to process flow measurement in “2 flow directions”, so that the current flowrate is displayed and the volumetric flow counted independent of the flow direction. The measured values may possibly be shown with a “-” sign.

This factory setting for the current and pulse outputs may possibly lead to measuring errors, particularly in the case of volume flow counting:

For example, if pumps are switched off and a “backflow” occurs which is not within the range of the low-flow cutoff (SMU), or if separate displays and counts are required for both flow directions.

To avoid faulty measurements, therefore, it may be necessary to change the factory setting of some or all of the following functions:

- low-flow cutoff SMU, Fct. 1.03, Sect. 5.3
- display, Fct. 1.04, Sect. 5.4
- current output I, Fct. 1.05, Sect. 5.6
- pulse output P, Fct. 1.06, Sect. 5.7

Operation see **Section 4 and 5**.


Standard factory settings

Function	Setting
1.01	Full-scale range $Q_{100\%}$
1.02	Time constant 3 s, for I, B1, B2 and display
1.03	Low-flow cutoff SMU ON: 1% OFF: 2%
1.04	Display flow rate totalizer(s) Messages Trend Updating Scaling m^3/hr or US Gal/min m^3 or US Gal no Mittelwert 1 sec. auto
1.05	Current output I function Range I I Max I Error 2 directions 4-20 mA 22 mA 22 mA
1.06	Pulse output P function pulse width pulse value 2 directions 50 ms 1 pulse/s

Function	Setting
1.07	Status output B1 flow directions
1.08	Control input B2 off
3.01	Language for display only English
3.02	Flowmeter diameter flow direction (see arrow on primary head) see nameplate } + direction
3.04	Entry code no
3.05	User unit Liter/hr or USMGal/day
3.06	Application: Flow steady
3.07	Hardware: Terminal B1 Terminal B2 Statusoutput Control input
3.08	Location ALTOMETER
3.09	Communication off

4 Operation of the signal converter

4.1 KROHNE operator control concept



4.2 Table of settable functions

Fct.	Display- Texts	Description and settings												
1.00	OPERATION	Operations menu												
1.01	FULL SCALE	<p>Full-scale range for flowrate Q_{100%}</p> <p><u>Select unit</u></p> <ul style="list-style-type: none"> • m³/hr • Liter/Sec • US.Gal/min <p>• user unit, factory set is Liter/hr or US MGal/day (see Fct. 3.05)</p> <p><i>Press → key to transfer to number setting.</i></p> <p><u>Setting ranges:</u></p> <p>The ranges are dependent on the meter size (DN) and the flow velocity (v):</p> $Q_{\min} = \frac{\pi}{4} DN^2 \times v_{\min} \quad Q_{\max} = \frac{\pi}{4} DN^2 \times v_{\max}$ <p><u>Nom. dia. /meter size</u></p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 33%;">$v_{\min} = 0,3 \text{ m/s (1 ft/s)}$</td> <td style="width: 33%;">$v_{\max} = 12 \text{ m/s (40 ft/s)}$</td> </tr> <tr> <td>• DN 2.5–1600 / ¹/₁₀ – 64:</td> <td></td> </tr> <tr> <td style="text-align: center;">0.0053</td> <td style="text-align: center;">–</td> </tr> <tr> <td style="text-align: center;">0.0237</td> <td style="text-align: center;">–</td> </tr> <tr> <td></td> <td style="text-align: center;">86 859 m³/hr</td> </tr> <tr> <td></td> <td style="text-align: center;">401 080 US Gal/min</td> </tr> </table> <p><i>Press ↵ key to return to Fct. 1.01 FULL SCALE.</i></p>	$v_{\min} = 0,3 \text{ m/s (1 ft/s)}$	$v_{\max} = 12 \text{ m/s (40 ft/s)}$	• DN 2.5–1600 / ¹ / ₁₀ – 64:		0.0053	–	0.0237	–		86 859 m ³ /hr		401 080 US Gal/min
$v_{\min} = 0,3 \text{ m/s (1 ft/s)}$	$v_{\max} = 12 \text{ m/s (40 ft/s)}$													
• DN 2.5–1600 / ¹ / ₁₀ – 64:														
0.0053	–													
0.0237	–													
	86 859 m ³ /hr													
	401 080 US Gal/min													
	VALUE P	<p>Pulse value has been changed.</p> <p>With the old pulse values the output frequency (F) would have been exceeded or not reached.</p> <p>$P_{\min} = F_{\min} / Q_{100\%}$ $P_{\max} = F_{\max} / Q_{100\%}$ Check new values!</p>												
1.02	TIMECONST.	<p>Time constant</p> <p><u>Select:</u></p> <ul style="list-style-type: none"> • ALL (applies to display and all outputs) • ONLY Current output (only display, current and status outputs) <p><i>Press ↵ key to transfer to number setting.</i></p> <p><u>Range:</u></p> <ul style="list-style-type: none"> • 0.2 – 99.9 Sec <p><i>Press ↵ key to return to Fct. 1.02 TIMECONST.</i></p>												
1.03	L.F.CUTOFF	<p>Low-flow cutoff (SMU)</p> <ul style="list-style-type: none"> • OFF (fixed values: ON = 0.1% / OFF = 0.2%) <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">PERCENT (variable values)</td> <td style="width: 20%; text-align: center;">ON</td> <td style="width: 20%; text-align: center;">OFF</td> </tr> <tr> <td></td> <td style="text-align: center;">1 – 19%</td> <td style="text-align: center;">2 – 20%</td> </tr> </table> <p><i>Press → key to transfer to number setting.</i></p> <p><u>Note:</u> Cutoff off value must be greater than cutoff on value.</p> <p><i>Press ↵ key to return to Fct. 1.03 L.F. CUTOFF.</i></p>	PERCENT (variable values)	ON	OFF		1 – 19%	2 – 20%						
PERCENT (variable values)	ON	OFF												
	1 – 19%	2 – 20%												
1.04	DISPLAY	Display functions												
	Contrast	<p>Set display contrast</p> <ul style="list-style-type: none"> • range from + 15 (high contrast) to - 15 (low contrast) <p><i>Press ↵ key to transfer to subfunction "Flow".</i></p>												
	Flow	<p>Set format for flow rate display</p> <ul style="list-style-type: none"> • ##### • ### . # • ## . ## • # . ##### • Auto <p><i>Press key → to move to unit selection.</i></p> <p><u>Selection unit:</u></p> <ul style="list-style-type: none"> • m³/hr • Liter/Sec • US Gal/min <p>user unit, factory set is Liter/hr or US MGal/day (see Fct. 3.05)</p> <p><i>Press ↵ key to transfer to subfunction "Totalizer".</i></p>												
	Totalizer	<p>Set format for display of volume</p> <p><u>Select decimal positions:</u></p> <ul style="list-style-type: none"> • ##### • ##### . # • ##### . ## • ##### . ### • ### . ##### • ## . ##### • # . ##### • Auto <p><i>Press → key to move to unit selection.</i></p> <ul style="list-style-type: none"> • m³ • Liter • US Gal <p>user unit, factory set is Liter or US MGal (see Fct. 3.05)</p> <p><i>Press ↵ key to transfer to subfunction "Messages".</i></p>												

Fct.	Display- Texts	Description and settings				
1.06	Pulsoutput P	Set Pulsoutput P				
	Function	Set Function <u>Selection:</u> <ul style="list-style-type: none"> • Off (switched off) • 1 Direction (1 flow direction) • 2 Directions (forward/reverse flow, F/R flow measurement) Press ↵ key to transfer to subfunction "Pulswidth".				
	Pulswidth	Set pulse width <u>Selection:</u> <ul style="list-style-type: none"> • 0.01 - 1.00 Sec (only for $F_{max} < 50$ pulse/s) • automatic (= 50% of the period duration of the 100% output frequency) • symmetrical (= pulse duty ratio 1:1 over total range) Press ↵ key to transfer to subfunction "Pulsvalue".				
	Pulsvalue	Set pulse value <u>pulse value per unit volume</u> <ul style="list-style-type: none"> • 1/m³ • 1/Liter • 1/US Gal • PulS/ user-defined unit, factory-set is Liter or US M.Gal (see Fct. 3.05) <u>pulse value per unit time</u> <ul style="list-style-type: none"> • PulSe/Sec (=Hz) • PulSe/min • PulSe/hr • PulSe/user-defined unit, factory-set is hr (see Fct. 3.05) Press ↵ key to return to Fct. 1.06 "Pulsoutput P".				
1.07	Output/Input B1	Assignment of terminal B1 see Fct. 3.07 Hardware: Either STATUS OUTPUT or CONTROL INPUT For settings, refer to one of the following descriptions.				
1.08	Output/Input B2	Assignment of terminal B2 see Fct. 3.07 Hardware: Either STATUS OUTPUT or CONTROL INPUT For settings, refer to one of the following descriptions.				
1.0_	Status output B1 and/or B2	Setting as status output <ul style="list-style-type: none"> • Off (status output switched off) • On (status output switched on, e.g. as operation indicator) EMPTY PIPE (signals that pipe is empty , only if option installed) • SIGN.I or P (F/R flow measurement) • Overflow I or P (overranging of outputs) • SMU I or P (signals when low-flow cutoff is active) • Inverse B1 • Trip Point: (press key ↵ to transfer to Characteristics) <table style="width: 100%; border: none;"> <tr> <td style="text-align: center;"><u>Selection:</u></td> <td style="text-align: center;">• + direction</td> <td style="text-align: center;">• - direction</td> <td style="text-align: center;">• 2 directions</td> </tr> </table> (press ↵ key to transfer to number setting) Setting range 005 - 150% • automatic range change (press ↵ key to transfer to number setting) Setting range 05 - 80% (= ratio of lower to upper range) • All Errors • Fatal error only Press ↵ key to return to Fct. 1.07 and/or 1.08 "Statusoutput"	<u>Selection:</u>	• + direction	• - direction	• 2 directions
<u>Selection:</u>	• + direction	• - direction	• 2 directions			
1.0_	Controlinput B1 and/or B2	Set as Control input <ul style="list-style-type: none"> • Off (switched off) • Ext.Range (external range change) Press ↵ key to transfer to number setting. <u>Setting range:</u> 05 - 80% (= ratio of lower to upper range from 1:20 to 1:1.25. Value must be greater than that of Fct. 1.03 L.F. CUTOFF). • Outp.Hold (hold value of outputs) • Outp.Zero (set outputs to min.values) • Total. Reset (reset totalizers) • Error. Reset (delete error messages) Press ↵ key to return to Fct. 1.07 and/or 1.08 "Statusoutput"				

Fct.	Display-Texts	Description and settings
	Field Frequenz	Set Magnetic field frequency (f_{Netz} = power frequency) <ul style="list-style-type: none"> • $\frac{1}{2} \times f_{\text{Netz}}$ • $\frac{1}{6} \times f_{\text{Netz}}$ • $\frac{1}{18} \times f_{\text{Netz}}$ • $\frac{1}{36} \times f_{\text{Netz}}$ Select with \uparrow key. Press \downarrow key to transfer to subfunction "Flow Direction". for DC devices to subfunction „Line Frequenz“
	Line Frequenz	Normal line frequency in your country This function is only provided for units with DC power supply <ul style="list-style-type: none"> • 50 Hz • 60 Hz Select with \uparrow key. Press \downarrow key to transfer to subfunction "Flow Direction".
	Flow Direction	Define flow direction (in F/R mode: forward flow). <ul style="list-style-type: none"> • + Direction • - Direction Select with \uparrow key. Press \downarrow key to return to Fct. 3.02 "Flowmeter".
3.03	Zero Point	Zero calibration <ul style="list-style-type: none"> • return (quit function without making change) • calculate (calculate new zero value) Press \downarrow key to start, duration approx. 15-90 seconds. Save new value, select with \uparrow key: <ul style="list-style-type: none"> • save no (do not save zero value) • save yes (save new zero value) • change (change zero value manually) Press \rightarrow key to transfer to unit selection: <ul style="list-style-type: none"> • m^3/h • Liter/s • US Gal/min • any unit, see Fct. 3.05 (factory setting: Liter/h) Press \rightarrow key to transfer to number setting. Value may be max. 10% of $Q_{100\%}$ Press \downarrow key to return to Fct. 3.03 "Zero Point".
3.04	Entrycode	Entry code required to enter setting mode? <ul style="list-style-type: none"> • NO (= entry with \rightarrow only) • YES (= entry with \rightarrow and Code 1: $\rightarrow \rightarrow \rightarrow \downarrow \downarrow \downarrow \uparrow \uparrow \uparrow$) Press \downarrow key to return to Fct. 3.04 "Entrycode".
3.05	User Units	Set any required unit for flowrate and counting
	Text Volumen	Set text for required flowrate unit (max. 5 characters) Factory-set: Liter or MGal . <u>Characters assignable to each place:</u> • A-Z, a-z, 0-9, or — (= blank character) Press \downarrow key to transfer to subfunction "Factor Volumen".
	Factor Volumen	Set conversion factor (FM) for volume Factory set 1.00000 for Liter or 2.64172E-4 for US MGal (exponent notation, here: 1×10^3 or 2.64172×10^{-4}). Factor FM = volume per 1m^3 . Setting range • 1.00000 E-9 to 9.99999 E+9 (= 10^{-9} to 10^{+9}) Press \downarrow key to transfer to subfunction "Text Time".
	Text Time	Set text for required time unit (max. 5 characters) Factory-set: hr. <u>Characters assignable to each place:</u> • A-Z, a-z, 0-9, or — (= blank character) Press \downarrow key to transfer to subfunction "Factor Time".
	Factor Time	Set conversion factor (F_T) for time Factory-set: 3.60000 E+3 for hour or 8.64000 E+4 for day (exponent notation, here: 3.6×10^3 or 8.64×10^4). <u>Set factor FT in seconds.</u> Setting range • 1.00000 E-9 to 9.99999 E+9 (= 10^{-9} to 10^{+9}) Press \downarrow key to return to Fct. 3.05 "User Units".
3.06	Application	Set application conditions
	Flow	Set characterization for flow <ul style="list-style-type: none"> • Steady (steady flow, max. 150% of $Q_{100\%}$) • Pulsating (pulsating flow, up to 1000% of $Q_{100\%}$ e.g. caused by reciprocating pumps, refer to Sect. 6.4) Press \downarrow key to transfer to subfunction "Empty Pipe".
	Empty Pipe	Signal when measuring tube is empty (refer to Sect. 6.3) <ul style="list-style-type: none"> • no • yes (possible only with built-in option) Press \downarrow key to return to Fct. 3.06 "Application".

Fct.	Display-Texts	Description and settings
3.07	Hardware	Assign outputs and inputs to terminals B1 and B2
	Terminal B1	Define function of terminal B1 (valid for Fct. 1.07) <ul style="list-style-type: none"> • Statusoutput • Controlinput (Select with ↑ key.) Press ↵ key to transfer to subfunction "Terminal B2".
	Terminal B2	Define function of terminal B2 (valid for Fct. 1.08) <ul style="list-style-type: none"> • Statusoutput • Controlinput (Select with ↑ key.) Press ↵ key to transfer to subfunction "Fieldcurrent".
	Fieldcurrent	Define field current supply <ul style="list-style-type: none"> • Intern • Extern (> DN 1600 / > 64" with power driver) Press ↵ key to return to Fct. 3.07 "Hardware".
3.08	Location	Set measuring point tag Factory setting: ALTOMETER Characters assignable to each place: <ul style="list-style-type: none"> • A-Z, a-z, 0-9 or „-“ (=blank character.) Press ↵ key to return to Fct. 3.08 "Location".
3.09	Communication	Set communication interface <ul style="list-style-type: none"> • Off (switched off) • HART (HART®-interface switched on)) • KROHNE (KROHNE RS 485-interface switched on), (only provided if daughter board installed (option).) • Address: „HART“ 00-15 / „KROHNE“ 000-239 • Baud rate: 1200, 2400, 4800, 9600 or 19200 (appears with selection "KROHNE" only") Press ↵ key to return to Fct. 3.09 "Communication".

4.3 Error messages in measuring mode

The following list gives all errors that can occur during process flow measurement. Errors shown in display when "Yes" set in Fct. 1.04 Display, subfunction "Messages".

Error messages	Description of error	Error clearance
Line Int.	Power failure Note: no counting during power failure	Cancel error in Reset-Quit menu, see Sect. 4.6. Reset totalizer if necessary.
Overflow I	Current output overranged (Flow > I Max)	Check and if necessary correct instrument parameters. After elimination of cause, error message deleted automatically.
Overflow P	Pulse output overranged. (Flow > I Max)	Check and if necessary correct instrument parameters. After elimination of cause, error message deleted automatically.
Totalizer	Totalizer has been reset.	Cancel error message in Reset/Quit. menu, see Sect. 4.6.
ADC	Analog / digital converter overranged	Error message deleted automatically after elimination of cause.
Fatal Error	Fatal error, all outputs set to "min. values"	Please consult factory.
Empty Pipe	Pipe has run dry. This message appears only when the " empty pipe identifier " option is installed and the function is switched on under Fct. 3.06 Application, submenu "Empty Pipe".	Fill pipe.

4.4 Reset totalizer and cancel error messages

Cancel error messages in RESET / QUIT menu

Key	Display	Description
	-----	----- / ---
↵	Code 2	--
↑ →		Error Quit
		... No
↑		... Yes
↵		Reset totalizer ...
↵	-----	----- / ---

Reset totalizer(s) in RESET / QUIT menu

Key	Display	Description
	-----	----- / ---
↵	Code 2	--
↑ →		Error Quit
↵		Reset totalizer ...
→		... No
↑		... Yes
↵	-----	----- / ---

4.5 Examples of setting the signal converter

As an example the **cursor**, flashing part of display, is shown below in **bold** type.

- **Change measuring range of current output and value for error messages** (Fct. 1.05):
- Change measuring range from 04-20 mA to **00-20 mA**
- Change value for error messages from 0 mA to **22 mA**

Key	Display	Description
→		If "Yes" set under Fct. 3.04 Entry Code, key in the 9-keystroke Code 1 now: → → → ↑ ↑ ↑ ↵ ↵ ↵
→	Fct. 1.00	Operation
→	Fct. 1.01	Full Scale
4 × ↑	Fct. 1.05	Currentoutput I
→		Function
→ ↵		Range I
→	04-20	mA
2 × ↑	00-20	mA
2 × ↵		I Error
→	0	mA
↑	22	mA
↵	Fct. 1.05	Currentoutput I
↵	Fct. 1.00	Operation
↵		Store Yes
↵	-----	----- / ---