# KROHNE

#### 05/98

# Electromagnetic flowmeters

- Primary heads
- Compact flowmeters

Installation instructions

VARIFLUX IFS 6000 F

IFM 6010 K IFM 6020 K IFM 6080 K

Pages 4-5 and 7-8

Pages 8-9







IFM 6080 K

IFS 6000 F

	Contents	
Sy:	stem description	2
Pro	oduct liability and warranty	2
Sta	andards and approvals	2
Iter	ms included with supply	3
1	Important information for installation: PLEASE NOTE	4-5
2	Suggestions for installation	5
3	Instrument nameplate	6
4	Flowmeter versions	7
5	Installation in the pipeline and torques	8
6	Limits	8-9
7	Grounding	10
8	Service	10
9	Spares and order numbers	10
10	Technical data	11
11	Dimensions and weights	12-14
Pri	nted form to accompany flowmeters returned to Krohne	15

#### System description

VARIFLUX electromagnetic flowmeters are precision measuring instruments designed for the linear flow measurement of process liquids.

The process liquids must be electrically conductive:

 $\geq 5 \,\mu$ S/cm  $\geq 20 \,\mu$ S/cm for demineralized cold water

The **full-scale range Q**<sub>100%</sub> can be set as a function of the **meter size**: DN 2.5 - 80 /  $^{1}/_{10}$ " - 3" Q<sub>100%</sub> = 0.01 - 220 m<sup>3</sup>/hr = 0.03 - 960 US Gal/min This is equivalent to a flow velocity of 0.3 - 12 m/s, or 1 - 40 ft/s.

#### Product liability and warranty

VARIFLUX electromagnetic flowmeters are designed solely for measuring the volumetric flowrate of electrically conductive, liquid process products.

Special codes and regulations apply to their use in hazardous locations, and these are referred to in the special "Ex" installation and operating instructions (supplied only with hazardous-duty equipment).

Responsibility as to suitability and intended use of these electromagnetic flowmeters rests solely with the operator.

Improper installation and operation of the flowmeters (systems) may lead to loss of warranty.

In addition, the "General conditions of sale" forming the basis of the purchase contract are applicable.

If VARIFLUX flowmeters need to be returned to Krohne, please note the information given on the last-but-one page of this manual. Krohne regret that they cannot repair or check your flowmeter(s) unless accompanied by the completed form sheet.

#### Standards and approvals

Please refer to the installation and operating instructions for the signal converter.

#### Items included with supply

#### IFS 6000 F primary head

- . primary head
- in the size as ordered
- certificate of calibration data

installation instructions

#### IFM 6010 K, IFM 6020 K and IFM 6080 K compact flowmeters

- compact flowmeter in the size as ordered •
- certificate of calibration data
- installation instructions .
- installation and operating instructions for the signal converter

\* not to ISO 2037

#### · Available meter sizes/types and connections

m D D C Ē Ē Ē D D D 2 DN 80 3 DN 80 76.1 3 |- |-DN 80 76.1 3 76 76.1 3 -

Items included with supply (Arrangement of gaskets and grounding rings see Sect. 7).

Flanged units:

with mounted grounding rings E and fitted gaskets D1. Gaskets D2 not included, to be provided by customer.

Other connections:

mounted adapter with fitted O-ring gaskets D1 and union nuts (counterparts for the pipeline, such as tapered connectors, union nuts,

hinged clamps and gaskets D2 not included, to be provided by customer).

#### Inside diameter of measuring tube and pipeline

Size Type		Inside diam of measurin for connection	eter Ø di Ig tube in mm (inch) ons to	Pipe standard DIN 11850	to	Pipe standard to ISO, SMS, RJT, JIS OD-Tube			
mm	inch	DIN	ISO, SMS, ect.	Meter size	Ø di mm	Meter size	Ødimm		
DN 2.5	1/10	2.5	2.5						
DN 4	1/8	4	4						
DN 6	1/4	6	6						
DN 10	3/8	10	10	] /					
DN 15	1/2	13	13	V					
DN 25	1	26	23	DN 25	26	DN 25/1"	23		
DN 40	11/2	38	36	DN 40	38	DN 40/11/2"	36		
DN 50	2	50	49	DN 50	50	DN 50/2"	49		
DN 65	21/2	66	60	DN 65	66	DN 65/2 <sup>1</sup> /2"	60		
DN 80	3	81	73	DN 80	81	DN 80/3"	73		

		Aseptic weld-on connections for pipes to DIN 11 850	Aseptic weld-on connections	for pipes to ISO 2037	Connection and pipe flanges to DIN 2501 / PN 40	Connection and pipe flanges to ANSI B 16.5 / 150, 300 lb	Connection and pipe flanges to JIS 2210 / 20 K	Dairy screw connections and hose nozzles (option) to DIN 11851	Screwed nine connections	to ISO 2853	Screwed pipe connections to SMS 1145	Clamp joints	to ISO 2852
nm	inch	mm	mm	inch	mm	inch	mm	mm	mm	inch	mm	mm	incl
N 2.5	1/ <sub>10</sub>	DN 10	12	-	DN 10	1/2	DN 10	DN 10	12	-	-	12	-
N 4	1/8	DN 10	12	-	DN 10	1/2	DN 10	DN 10	12	-	-	12	-
N 6	1/4	DN 10	12	-	DN 10	1/2	DN 10	DN 10	12	-	-	12	-
N 10	3/ <sub>8</sub>	DN 10	12	-	DN 10	1/2	DN 10	DN 10	12	-	-	12	-
N 15	1/2	DN 15	18	-	DN 15	1/2	DN 15	DN 15	18	-	-	18	-
N 25	1	DN 25	25	1 *	-	-	-	DN 25	25	-	25	25	-
N 40	1 <sup>1</sup> / <sub>2</sub>	DN 40	38	1 <sup>1</sup> / <sub>2</sub>	-	-	-	DN 40	38	1 <sup>1</sup> / <sub>2</sub>	38	38	1 1/
N 50	2	DN 50	51	2	-	-	-	DN 50	51	2	51	51	2
N 65	2 <sup>1</sup> / <sub>2</sub>	DN 65	63.5	2 <sup>1</sup> / <sub>2</sub>	-	-	-	DN 65	63.5	2 <sup>1</sup> / <sub>2</sub>	63.5	63.5	2 1/
	2		70.4	2				DNLOO	70.4	0	70	704	0

#### 1 Important information for installation: PLEASE NOTE

#### Handling

Do not lift flowmeter by the signal converter housing or the terminal box.

Do not set flowmeter down on signal converter housing or terminal box.





• Use only solventless detergents to clean the signal converter housing (polycarbonate).

#### • Temperatures

For operating pressure and vacuum load based on connection standards, see Section 6 "Limits".

	Ambient temperature	Product temperature				
Compact systems	-25 to +60 °C (-13 to +140 °F)	-20 to + 60 °C (-4 to +140 °F)				
	-25 to +40 °C (-13 to +104 °F)	-20 to +140 °C (-4 to +284 °F)				
- EEx version	-25 to +40 °C (-13 to +104 °F)	-20 to +140 °C (-4 to +284 °F)				
IFS 6000 F	-25 to +60 °C (-13 to +140 °F)	-20 to + 60 °C (-4 to +140 °F)				
- flange connections	-25 to +40 °C (-13 to +104 °F)	-20 to +180 °C (-4 to +356 °F)				
- other connections	-25 to +40 °C (-13 to +104 °F)	-20 to +140 °C (-4 to +284 °F)				
- EEx version	-25 to +40 °C (-13 to +104 °F)	-20 to +140 °C (-4 to +284 °F)				

- Location and position as required, but electrode axis X - • - • - • - X must be approximately horizontal in a horizontal pipe run.
  - Y terminal box or converter housing



- Measuring tube must be completetly filled at all times.
- **Direction of flow is arbitrary.** Arrow on flowmeter can normally be ignored. For exceptions, refer to Section "Factory settings" in the installation and operating instructions for the signal converter.
- Stud bolts and nuts: to fit, make sure there is sufficient room next to the pipe flanges.
- Vibration: support the pipeline on both sides of the compact flowmeter. Level of vibration in conformity with IEC 068-2-34: 20-500 Hz, random / 2g runs / 30 minutes / x, y, z directions.
- **Do not expose to direct sunlight,** fit a sunshade if necessary, not included with flowmeter, to be provided by customer.

- Strong electromagnetic fields, avoid in vicinity of flowmeter.
- Straight inlet run minimum of 5 × DN and outlet run minimum of 2 × DN, (DN = meter size), measured from the electrode axis.
- Vortex and corkscrew flow: increase length of inlet and outlet runs or install flow conditioners.
- **Mixing different process liquids:** install flowmeter upstream of mixing point or at an adequate distance downstream (minimum of 30 x DN), otherwise display may be unsteady.
- Plastic pipes and internally coated metal pipelines: grounding rings required, see Section 7 "Grounding".
- Insulated pipeline: do not insulate flowmeter.
- Zero setting not necessary. To check, it should be possible to set "zero" flow velocity in the completely filled measuring tube. Shutoff valves should therefore be provided either downsteam of the flowmeter or upsteam and downstream of the flowmeter.

#### 2 Suggestions for installation

To avoid measuring errors due to gas/air inclusion or to pipe runing empty please observe the following:



#### Horizontal pipe run

Install in slightly ascending pipe section. If not possible, assure adequate velocity to prevent air, gas or vapor from collecting in upper part of flow tube.



Install meter in low section of pipe.



**Downpipe over 5 m (16 ft) length** Install air valve  $\otimes$  downstream of

Install air valve  $\otimes$  downstream of flowmeter.



#### Long pipeline Always install control and shutoff valves downstream of flowmeter.



Pumps Never install flowmeter on pump suction side.



#### IFS 6000 F

separate primary head



Teflon® is a registered trademark of Du Pont

**Instrument nameplate for compact flowmeters** see installation and operating instructions for the signal converter.

#### **Electrode Materials**

HC	Hastelloy C4
PT	Platinum
TA	Tantalum
TI	Titanium
V4A	Stainless steel 1.4571

#### 4 Flowmeter versions

- **IFS 6000 F** Separate primary head (F), electrically connected to the signal converter by signal and field current cables.
- **IFM 6010 K Compact flowmeter (K),** IFC 010 K or IFC 020 K signal converter mounted direct **IFM 6020 K** on the primary head.
- IFM 6080 K Compact flowmeter (K), IFC 090 K signal converter mounted direct on the primary head.

#### Versions for hazardous locations

IFS 6000 F and IFM 6080 K are approved as electrical equipment to the harmonized European Standards and to Factory Mutual (FM).

Test certificate, certificate of conformity and wiring instructions for these devices are attached to the "**Ex**" installation instructions, provided only with hazardous-duty equipment.

#### 5 Installation in the pipeline

- Installation material, see page 3.
- Pipe and operating pressures, see Section 6 "Limits".
- Flange spacing

 dimension "a" + 2 x gasket thickness of D2
 (dimension "a": see Sect. 11 "Dimensions and weights"; arrangement of gaskets: see Sect. 7 "Grounding").

#### High-temperature pipelines

Where process temperatures exceed 100 °C/212 °F, provide for facilities to compensate for longitudinal expansion on heat-up of the pipeline. For **short** pipelines use resilient gaskets and for **long** pipelines install flexible pipe elements (e.g. elbows).

#### Position of flanges

Install flowmeter in line with the pipe axis. Pipe flange faces must be parallel to each other, max. permissible deviation:  $L_{max}$  -  $L_{min} \leq 0.5 \text{ mm}$ 





#### • Torques

# For all flanged instruments to DIN, ANSI and JIS

Tighten down stud bolts and nuts uniformly in the sequence (1-8) shown in the drawing. Max. torque: 32 Nm ~ 3.2 kpm ~ 23.1 ft x lbf

#### For all other connections to DIN and ISO Tighten down to metal stop.



Connections	Connection meter size		Max. operating pressure in bar/psig at product temperature of														
			< 40°C		< 60°C		< 70°C		)°C	< 10	0°C	< 12	20°C	< 140°C **		< 18	80°C **
		(< 1	05°F)	(< 1	40°F)	(< 1	58°F)	(< 1	95°F)	(< 2	10°F)	(< 2	250°F)	(< 2	85°F)	(< 3	55°F)
Flange DIN 2501/PN 40	DN 10*-15	39	(566)	37	(537)	36	(522)	34	(493)	33	(479)	32	(464)	30	(435)	28	(406)
Flange JIS 2210/20 K	DN 10*-15	39	(566)	37	(537)	36	(522)	34	(493)	33	(479)	32	(464)	30	(435)	28	(406)
Flange ANSI B 16.5: 150 lb	1/2"*	19.6	6 (284)	19.0	0 (276)	18.	7 (271)	18.1	(263)	17.	7 (257)	17.(	) (247)	16.2	2 (235)	14.7	(213)
300 lb	1/2"*	39	(566)	37	(537)	36	(522)	34	(493)	33	(479)	32	(464)	30	(435)	28	(406)
Aseptic weld-on connection	DN 10*-40	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	-	
for pipes to DIN 11 850	DN 50-80	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	-	
Aseptic weld-on connection	12*-38/1"-1 <sup>1</sup> / <sub>2</sub> "	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	-	
for pipes to ISO 2037	51-76.1/2"-3"	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	-	
Dairy screw connection DIN 11 851	DN 10*-40	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	-	
	DN 50-80	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	-	
Screwed pipe connection ISO 2853	12*-38 mm	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	40	(580)	-	
	51-76.1 mm/11/2"-3.0"	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	25	(360)	-	
Screwed pipe connection SMS 1145	25-76 mm	6	(90)	6	(90)	6	(90)	6	(90)	6	(90)	6	(90)	-		-	
Clamp joint ISO 2852	12*-51 mm/1 <sup>1</sup> / <sub>2</sub> "-2.0"	16	(230)	16	(230)	16	(230)	16	(230)	16	(230)	16	(230)	-		-	
	63.5-76.1 mm/2 <sup>1</sup> /2"-3.0"	10	(150)	10	(150)	10	(150)	10	(150)	10	(150)	10	(150)	-		-	
Vacuum load all sizes			mbar	abs.													

#### \* size DN 2.5 - 10 / 1/10" - 3/8"

\*\* max. process temperature 140°C (285°F) for compact flowmeters ambient temperature here max. 40°C/104°F.

#### 7. Grounding

- Warning: All flowmeters must be properly grounded to avoid personnel shock hazard.
- The ground conductor should not transmit any interference voltages, therefore do not ground any other electrical devices together with this conductor.

#### Separate primary head IFS 6000 F with terminal box

- A functional ground FE must always be connected.
- Signal converters with a field power supply of > 125 mA / > 60 V: Because of the higher field current from the signal converter, a PE protective conductor must be connected to the IFS 6000 F primary head, see grounding diagrams.

#### Supply power > 50 V AC

- Grounding is via the PE protective ground conductor incorporated in the power supply cable, see also Section "Connection to power" in the installation and operating instructions for the signal converter.
- EXCEPTION: Do not connect up the PE protective ground conductor in the terminal box if e.g. compact units are operated in the proximity of electric furnaces, electrolysis plants, etc., and large potential differences occur in the pipeline system. An FE functional ground must simultaneously take over the function of the protective conductor (combined protective/functional ground). Refer to appropriate national codes for specific requirements for this type of installation, which may require the addition of a ground fault detection circuit interrupter.

#### Power supply 24 V AC or DC

- Protective separation (PELV) must be ensured (VDE 0100/VDE 0106 or IEC 364/IEC 536 or equivalent national regulations).
- An FE functional ground conductor must be connected for measurement reasons.



#### 8.1 Replacement of the separate primary head

#### Switch off power source before commencing work!

- 1) Note down terminal assignment before dismantling the "old" primary head.
- 2) Install the new primary head as described in the supplied installation instructions.
- **3)** Make electrical connection at the signal converter as described in the installation and operating instructions for the signal converter.
- 4) Specific calibration data are defined during factory calibration for each primary head, which are indicated on the instrument nameplate. This includes the primary constant GK and the magnetic field frequency. These data need to be reset in the signal converter.
- 5) If the size of primary head is also different from the old one, the full-scale range Q<sub>100%</sub> and the meter size will need to be reset.
- 6) After resetting the signal converter, carry out a zero point check.
- 7) If necessary, reset the internal electronic totalizer of the signal converter.

#### 8.2 Replacement of O-ring gaskets with adapters

- Unscrew union nuts.
  <u>Caution</u>: keep hold of the flowmeter to prevent it from dropping out of the pipeline.
- Remove the flowmeters from the pipeline.
- Remove O-rings (gaskets D1, see grounding diagram in Sect. 7) from the adapter grooves.
- Apply grease to new gaskets D1 (Paraliq GTE 703, Silubin or Similar).
- Insert O-rings into the adapters.
- Slide the flowmeter between the adapters.
- Tighten union nuts down to metal stop.



#### 9 Spare parts and order numbers

O-ring gaskets D1 between coupler and measuring tube Material: EPDM, FDA-approved (Gasket arrangement, see Sect. 7)

Meter size		Order No.
mm	inch	
2.5	1/10	5.30001.03
4	1/6	5.30001.04
6	1/4	5.30001.05
10	3/8	5.31116.02
15	1/2	5.31116.03
25 DIN	-	5.30026.03
25 ISO	1 ISO	5.30026.06
40 DIN	-	5.30034.03
40 ISO	1 <sup>1</sup> /2 ISO	5.30034.04
50 DIN	-	5.30038.03
50 ISO	2 ISO	5.30038.03
65 DIN	-	5.30034.06
65 ISO	3 ISO	5.30034.04
80 DIN	-	5.30034.09
80 ISO	4 ISO	5.30034.05

O-ring gaskets D1 between measuring tube and grounding rings

(gasket arrangement, see Sect. 7)

Meter size		Material	Order No.
DN 2.5 - 15	1/10"- 1/2"	Viton	5.30014.02
		Kalrez	5.30014.03
		EPDM	5.30014.04

Size/type	DN 2.5 - 80 and <sup>1</sup> /10" - 3"						
Available connections	see page 3						
Electrical conductivity	$\geq$ 5 $\mu S/cm$ ( $\geq$ 20 $\mu S/cm$ for demineralized water)						
Ambient temperature							
Standard	-25  to  +60  °C / -13  to  +140  °F						
Hazardous duty versions	-20 to +40 °C / - 4 to +104 °F						
Max. permissible operating data	see table "limits" on next page						
Vacuum load	0 mbar abs / 0 psia						
Insulation class of field coils	H						
Electrode design	permanently fitted ( $\geq$ DN 25 / $\geq$ 1" surface polished)						
Power for field coils	> 60 V from signal converter						
Grounding rings	standard for flanged connections						
Protection category (IEC 529/EN 60 529)	IP 67, equivalent to NEMA 6						
Materials <u>Measuring tube</u> <u>Liner</u> DN 2.5 - 10 mm / <sup>1</sup> /10" - <sup>3</sup> /8" DN 15 - 80 mm / <sup>1</sup> /2" - 3" <u>Electrodes</u> Standard	stainless steel 1.4301 / 304-AISI clear, virgin Teflon <sup>®</sup> -PFA, FDA-approved reinforced with sintered metal bearing bush reinforced with steinless steel mesh Hastelloy C4						
Special version	stainless steel 1.4571/316 Ti-AISI, titanium, tantalum, platinum others on request						
Flanges to DIN 2501 ANSI B 16.5 JIS 2210	Standard: stainless steel 1.4301/304-AISI Special version: stainless steel 1.4404/316L-AISI						
Aseptic weld-on connection for pipes to DIN 11 850 ISO 2037 Dairy screw connection and tube nozzles (option) to DIN 11 851 Screwed pipe connection to SMS 1145	stainless steel 1.4404/316L-AISI						
Screwed pipe connection to ISO 2853 Clamp joint to ISO 2852 Housing	J						
DN 2.5 - 15 mm / <sup>1</sup> /10" - <sup>1</sup> /2" DN 25 - 80 mm / 1" - 3"	stainless steel 1.4462 Duplex stainless steel 1.4301/304-AISI						
Ierminal box Standard Special version	die cast aluminium, paint finish stainless steel 1.4301/304-AISI, others on request						
<u>Grounding rings</u> (only for flange versions)	stainless steel 1.4571/316 Ti-AISI, others on request						

Teflon<sup>®</sup> is a registered trademark of Du Pont

#### PLEASE NOTE

The **total dimension for the height** is obtained from **dimension b** (see table) **plus the height** of the terminal box or the signal converter, see drawings.

The **total weight** is made up of the weight of the signal converter (see table) **plus** the weight of the terminal box or signal converter, see below.

#### **Terminal box**





۲

IFC 010 K and IFC 020 K

signal converter

#### IFC 090 K signal converter



Weight approx. 2.3 kg (5.1 lb)

#### Weight approx. 0.5 kg (1.1 lb)

Weight approx. 1.6 kg (3.6 lb)

## Flange connections to DIN, JIS and ANSI

Flowmeter				Dimensions in mm and (inch)									
Size/type Flanges				a	b <sub>max</sub>		ØD d						
DIN/JIS ANSI DIN/JIS ANSI			ANSI			DIN/PN 40	JIS/20 K	ANSI/150 lb	ANSI/300 lb	]	in kg (lb)		
DN 2.5	1/10"												
DN 4	1/8"												
DN 6	1/4"	DN 10	1/2"	130 (5.12)	142 (5.59)	90 (3.54)	90 (3.54)	88.9 (3.50)	95.2 (3.75)	51 (2.01)	2.6 (5.8)		
DN 10	3/8"	1											
DN 15	1/2"	DN 15				95 (3.74)	95 (3.74)						

DN 2.5 - 15 / 1/10" - 1/2"



(Continuation see next page)

# Dimensions without connectors/adapters

Size/type		Dimensions	in mm	Approx. weight in kg (lb) without adapters		
mm	inch	LM	b <sub>max</sub>	d	е	
DN 2.5	1/10					
DN 4	1/8					
DN 6	1/4	180 (7.09)	142 (5.59)	51 (2.01)	44 (1.73)	1.2 (2.7)
DN 10	3/8					
DN 15	1/2					
DN 25	1	186 (7.32)	146 (5.75)	40 (1.57)	80 (3.15)	1.8 (4.0)
DN 40	11/2	200 (7.87)	164 (6.46)	49 (1.93)	98 (3.86)	3.2 (7.1)
DN 50	2	204 (8.03)	196 (7.72)	65 (2.56)	130 (5.12)	4.5 (10.0)
DN 65	21/2	250 (9.84)	221 (9.70)	79 (2.07)	156 (6.14)	7.0 (15.5)
DN 80	3	266 (10.47)	221 (0.70)	10 (3.07)	150 (0.14)	7.0 (10.0)

DN 2.5 - 15 / 1/10" - 1/2"



DN 25 - 80 / 1" - 3"



## Dimensions with mounted connectors/adapters (1)

#### Aseptic weld-on connection for pipes to DIN 11 850

Connection meter size	dia. D	LA	а	dia. D1	dia. D2	dia. D3
DN 10 1)	28 (1 50)	20.0 (1.19)	190 (7.00)	10 (0.39)	12 (0.47)	15 (0.59)
DN 15	38 (1.50)	30.0 (1.18)	180 (7.09)	16 (0.63)	18 (0.71)	21 (0.83)
DN 25	63 (2.48)	25.0 (0.98)	186 (7.32)	26 (1.02)	28 (1.10)	31 (1.22)
DN 40	78 (3.07)	23.0 (0.91)	200 (7.87)	38 (1.50)	40 (1.57)	43 (1.69)
DN 50	92 (3.62)	22.0 (0.87)	204 (8.03)	50 (1.97)	52 (2.05)	55 (2.17)
DN 65	112 (4.41)	21.0 (0.83)	250 (9.84)	66 (2.60)	68 (2.68)	72 (2.83)
DN 80	127 (5.00)	29.0 (1.14)	266 (10.47)	81 (3.19)	83 (3.27)	87 (3.43)

#### Aseptic weld-on connection for pipes to ISO 2037

Connection meter size		dia. D	LA	а	dia. D1	dia. D2	dia. D3
12 mm 1)	-	29 (1 50)	20.0 (1.19)		10.0 (0.39)	12.0 (0.47)	15.0 (0.59)
18 mm	-	36 (1.50)	30.0 (1.18)	180 (7.09)	16.0 (0.63)	18.0 (0.71)	21.0 (0.83)
25 mm	1 2)	63 (2.48)	22.0 (0.87)		22.6 (0.89)	-	25.6 (1.01)
38 mm	11/2"	78 (3.07)	26.5 (1.04)	207 (8.15)	35.6 (1.40)	-	38.6 (1.52)
51 mm	2"	92 (3.62)	28.5 (1.12)	217 (8.54)	48.6 (1.91)	-	51.6 (2.03)
63.5 mm	21/2"	112 (4.41)	27.5 (1.09)	263 (10.35)	60.3 (2.37)	-	64.1 (2.52)
76.1 mm	3"	127 (5.00)	21.3 (1.00)		72.9 (2.87)	-	76.7 (3.02)



1) for sizes DN 2.5 - 10 / 1/10" - 3/8"

2) not to ISO 2037

(Continuation see next page)

# Dimensions with mounted connectors/adapters (2)

Connection meter size	dia. D	L <sub>A</sub>	а	
DN 10 <sup>1)</sup>	29 (1 50)		214 ( 0 42)	
DN 15	36 (1.50)	47.0 (1.85)	214 (0.43)	
DN 25	63 (2.48)		230 (9.06)	
DN 40	78 (3.07)	49.0 (1.93)	252 (9.92)	
DN 50	92 (3.62)	50.0 (1.97)	260 (10.24)	
DN 65	112 (4.41)	53.0 (2.09)	314 (12.36)	
DN 80	127 (5.00)	66.0 (2.60)	340 (13.39)	



#### Screwed pipe connection to ISO 2853

Dairy screw connection to DIN 11851

Connection met	er size	dia. D	LA	а	
12 mm 1)	-	29 (1 50)	52 0 (2 00)		
18 mm	-	30 (1.50)	53.0 (2.09)	226 (8.90)	
25 mm	-	63 (2.48)	45.0 (1.77)		
38 mm	<b>1</b> <sup>1</sup> / <sub>2</sub> "	78 (3.07)	49.5 (1.95)	253 (9.96)	
51 mm	2"	92 (3.62)	51.5 (2.03)	263 (10.35)	
63.5 mm	2 <sup>1</sup> / <sub>2</sub> "	112 (4.41)	(4.41) 50 5 (1 99) 309		
76.1 mm	3"	127 (5.00)	50.5 (1.55)	505 (12.17)	



#### Screwed pipe connection to SMS 1145

Connection meter size	dia. D	LA	а	
25 mm <sup>1)</sup>	63 (2.48)	38.5 (1.52)	213 (8.39)	
38 mm	78 (3.07)	48.0 (1.89)	250 (9.84)	
51 mm	92 (3.62)	50.0 (1.97)	260 (10.24)	
63.5 mm	112 (4.41)	F2 0 (2 00)	214 (12 26)	
76 mm	127 (5.00)	55.0 (2.09)	314 (12.30)	



#### Clamp joint ISO 2852

Connection me	eter size	dia. D	L <sub>A</sub>	а
12 mm <sup>1)</sup>	-	20 (1 50)	40 E (1 0E)	210 (9.62)
18 mm	-	36 (1.50)	49.5 (1.95)	219 (0.02)
25 mm	-	63 (2.48)	45.0 (1.77)	226 (8.90)
38 mm	11/2"	78 (3.07)	49.5 (1.95)	253 (9.96)
51 mm	2"	92 (3.62)	51.5 (2.03)	263 (10.35)
63.5 mm	2 <sup>1</sup> / <sub>2</sub> "	112 (4.41)	50 5 (1 00)	200 (12 17)
76.1 mm	3"	127 (5.00)	50.5 (1.99)	309 (12.17)

## If you need to return flowmeters for testing or repair to Krohne

Your electromagnetic flowmeter

- has been carefully manufactured and tested by a company with ISO 9001 certification
- and volumetrically calibrated in one of the world's most accurate test rigs.

If installed and operated in accordance with these operating instructions, your flowmeter will rarely present any problems.

Should you nevertheless need to return a flowmeter for checkout or repair, please pay strict attention to the following points:

Due to statutory regulations concerning protection of the environment and the health and safety of our personnel, Krohne may only handle, test and repair returned flowmeters that have been in contact with liquids if it is possible to do so without risk to personnel and environment. This means that Krohne can only service your flowmeter if it is accompanied by a certificate in line with the following model confirming that the flowmeter is safe to handle.

If the flowmeter has been operated with toxic, caustic, flammable or water-endangering liquids, you are kindly requested

 to check and ensure, if necessary by rinsing or neutralizing, that all cavities in the flowmeter are free from such dangerous substances.
 (Directions on how you can find out whether the primary

head has to be opened and then flushed out or neutralized are obtainable from Krohne on request.)

 to enclose a certificate with the flowmeter confirming that the flowmeter is safe to handle and stating the liquid used.

Krohne regret that they cannot service your flowmeter unless accompanied by such a certificate.

#### SPECIMEN certificate

Company:	Address:		
Department:	Name:		
Tel. No.:			
The enclosed electromagnetic flowmeter			
Туре:	Krohne Order No. or Series No.:		
has been operated with the following liquid:			
Because this liquid is water-endangering * / toxic * / caustic * / flammable * we have - checked that all cavities in the flowmeter are free from such su - flushed out and neutralized all cavities in the flowmeter * (* delete if not applicable)	bstances *		
We confirm that there is no risk to man or environment through any residual liquid contained in this flowmeter.			
Date: Signature:			
Company stamp:			